



All dimensions shown are in millimetres

All steel construction: **1.5mm header thickness**  
**dia 25mm x 1.25mm tubes**

Connections: **1.2m long flying lead (2 core)**

Manufactured for Bisque by Zehnder of Germany

Model	Output		Weight kg	Height ± 2mm	Length ± 1.5%	Depth ± 2mm
	Watts	BTU				
4FE-40-55/GF	750	2559	24	475	594	136
4FE-40-74/GF	1000	3412	32	475	778	136
4FE-40-92/GF	1250	4265	40	475	962	136
4FE-40-106/GF	1500	5118	46	475	1100	136
4FE-50-46/GF	750	2559	24	575	502	136
4FE-50-64/GF	1000	3412	33	575	686	136
4FE-50-74/GF	1250	4265	38	575	778	136
4FE-50-87/GF	1500	5118	45	575	916	136
4FE-60-41/GF	750	2559	26	675	456	136
4FE-60-55/GF	1000	3412	34	675	594	136
4FE-60-74/GF	1250	4265	45	675	778	136
4FE-60-87/GF	1500	5118	53	675	916	136
4FE-60-110/GF	2000	6824	67	675	1146	136

## Tools & Material Required

Wall plugs - 10mm  
 Screws - 7mm diameter x 60mm length  
 Wall plugs - 10mm  
 Tape measure  
 Spanner - 13mm  
 Socketdriver - 10mm long reach  
 Electric drill  
 Masonry drill bit - 10mm diameter  
 Spirit level

Key	Component	Qty
A	Wall Plug*	2
B	Bracket	2
C	Screw - Hex Head, 7mm dia x 60mm*	2
D	Clamp Assembly	2
E	Security Clip	2

\* Wall Plugs & Screws not supplied

## Assembly Instructions

- Place radiator in desired location and mark out position of holes on wall near top & ends of radiator.
- Drill 10mm diameter holes in wall to a minimum depth of 65mm and insert wall plugs (A).
- Screw brackets (B) into wall using screws (C).
- Loosely fit clamp assemblies (D) onto radiator tubes.
- Place radiator in position and locate clamp assemblies (D) into the slots in the brackets (B).
- Tighten up clamp assemblies (D) and fix security clip (E) over clamps (C).

Electric radiators should be fitted only by a qualified electrician and must be connected to a cable outlet in the bathroom in accordance with I.E.E. wiring regulations. The electrical connection should be made to a '13 amp fused fixed spur' located outside the bathroom.

*Note: for maintenance purposes, cable outlets must remain accessible and cables must not be buried directly into walls.*

## Wiring Guide

Brown - live  
 Grey/Blue - neutral  
 Black - pilot wire. **This wire should NOT be wired to earth under any circumstances.**

### Caution:

To avoid overheating, this appliance must not be covered.  
 The control and thermostat must be kept clear at all times

