

Tools & Material Required

Wall plugs - 10mm
 Screws - 7mm diameter x 60mm length
 Suitable valves
 PTFE tape
 Silicone thread sealant
 Tape measure
 Allen key - 13mm & 12mm (when installing Bisque valves)
 Spanner - 13mm & 14mm
 Socketdriver - 10mm long reach
 Electric drill
 Masonry drill bit - 10mm diameter
 Spirit level

Key	Component	Qty
A	Air Vent - 1/2" (factory fitted)	1
B	Wall Plug*	2
C	Bracket	2
D	Screw - Hex Head, 7mm dia x 60mm*	6
E	Clamp Assembly	2
F	Security Clip	2
G	Air Vent Key	1

* Wall Plugs & Screws not supplied

Note:

The brackets for this product have recently changed. If you have the old style, please call our sales team for the relevant fitting instructions.

Assembly Instructions

Sufficient PTFE tape must be applied to valve-tail threads prior to their installation.
 Silicone thread sealant should be applied to all threaded components manufactured with 'O-rings'.

Fit valve tails, using correct size Allen key.

Drill 10mm diameter holes in wall to a minimum depth of 65mm and insert wall plugs (B).

Screw brackets (C) into wall using screws (D).

Loosely fit clamp assemblies (E) onto radiator tubes.

Lift radiator until the clamp assemblies (E) locate onto the brackets (C) and lower the radiator to the floor.

Tighten clamp assemblies (E) onto radiator tubes.

Mark out the position of the holes through the feet onto the floor. Lift the radiator off the brackets (C) and drill holes in the floor.

Reposition the radiator onto the brackets (C) and fix the feet to the floor with four screws (D).

Fix security clip (F) into position over clamps (E).

Plumb radiator to heating circuit with flow opposite air vent.

