



All dimensions shown are in millimetres

All steel construction: **dia 25mm x 1.2mm tubes**  
**dia 26mm x 1.5mm headers**

Connections: **1.2m long flying lead (3 core)**

Immersion heater rating: **IPX4 or better**

Manufactured for Bisque by Zehnder

Model	White Finish Output Watts	Chrome Finish Output Watts	Weight kg	Height ± 2mm	Length ± 2mm	Fixing Ctrs H ± 2mm	Fixing Ctrs V ± 2mm
SFTE-80-50/F	400	200	12	796	496	458	680
SFTE-80-60/F	500	200	15	796	596	558	680
SFTE-120-50/F	600	400	18	1196	496	458	1080
SFTE-120-60/F	600	400	21	1196	596	558	1080
SFTE-185-50/F	600	600	29	1876	496	458	1760
SFTE-185-60/F	600	600	33	1876	596	558	1760

**Tools & Material Required**

- Tape measure
- Electric drill
- Masonry drill bit - 8mm diameter
- Spirit level
- Stepladder (for taller radiators)

Key	Component	Qty
A	Bracket Post	4
B	Spacer	4
C	Wall Plug	4
D	Bracket	4
E	Screw - 6mm dia x 50mm	4
F	Washer	4
G	Grub Screw	4
H	Allen Key	1

**Assembly Instructions**

- Screw bracket posts (A) & spacers (B) onto studs on the rear of the radiator.
- Accurately mark out bracket holes on wall using spirit level.
- Drill four 8mm diameter holes to a minimum depth of 65mm & insert wall plugs (C).
- Screw brackets (D) into wall plugs (C) with screws (E) & washers (F).
- Slide bracket post (A) on radiator into bracket (D) and secure in position by tightening grub screw (G) with allen key (H).

Electric radiators should be fitted only by a qualified electrician and must be earthed and connected to a cable outlet in the bathroom in accordance with I.E.E. wiring regulations. The electrical connection should be made to a '5 amp fused fixed spur' located outside the bathroom.

*Note: for maintenance purposes, cable outlets must remain accessible and cables must not be buried directly into walls.*

